



CAMSHAFT POSITION SENSOR

REMOVAL

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE CAMSHAFT POSITION SENSOR**
 - (a) Disconnect the camshaft position sensor connector.
 - (b) Remove the bolt, then remove the camshaft position sensor.



ES



INSPECTION

1. **INSPECT CAMSHAFT POSITION SENSOR**
 - (a) Check the resistance.
 - (1) Using an ohmmeter, measure the resistance between the terminals.

Standard

Tester Connection	Specified Condition
1 (G+) - 2 (G-)	835 to 1,400 Ω at COLD
1 (G+) - 2 (G-)	1,060 to 1,645 Ω at HOT


HINT:


Cold and Hot mean the temperature of the coils themselves. Cold is from -10 to 50°C (14 to 122°F) and Hot is from 50 to 100°C (122 to 212°F).

If the result is not as specified, replace the camshaft position sensor.

INSTALLATION

1. **INSTALL CAMSHAFT POSITION SENSOR**
 - (a) Apply a light coat of engine oil to the O-ring of the camshaft position sensor.





- (b) Install the camshaft position sensor with the bolt.
Torque: 8.5 N*m (87 kgf*cm, 75 in.*lbf)
NOTICE:
Make sure that the O-ring is not cracked or jammed when installing.

- (c) Connect the camshaft position sensor connector.

- 2. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**
Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)