



TIRE AND WHEEL

RECOMMENDED TOOLS

	<p>09082-00040</p>	<p>TOYOTA Electrical Tester</p>	
	<p>(09083-00150)</p>	<p>Test Lead Set</p>	

PP

EQUIPMENT

Dial indicator with magnetic base	
Tire pressure gauge	
Wheel balancer	
Torque wrench	

