



# CIRCUIT OPENING RELAY

## INSPECTION

### 1. INSPECT CIRCUIT OPENING RELAY ASSEMBLY

- (a) Check the resistance.
  - (1) Using an ohmmeter, measure the resistance between the terminals.

#### Standard

Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (Apply battery voltage to terminals 1 and 2)

If the result is not as specified, replace the circuit opening relay assembly.