



## FREEZE FRAME DATA

### 1. DESCRIPTION

Freeze frame data record the engine conditions (fuel system, calculated load, engine coolant temperature, fuel trim, engine speed, vehicle speed, etc.) when a malfunction is detected. When troubleshooting, it can help determine if the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was LEAN or RICH, and other data, from the time the malfunction occurred.

#### HINT:

If it is impossible to replicate the problem even though a DTC is detected, confirm the freeze frame data.

The ECM records engine conditions in the form of freeze frame data every 0.5 seconds. Using the intelligent tester, five separate sets of freeze frame data, including the data values at the time when the DTC was set, can be checked.

- 3 data sets before the DTC was set
- 1 data set when the DTC was set
- 1 data set after the DTC was set

These data sets can be used to simulate the condition of the vehicle around the time of the occurrence of the malfunction. The data may assist in identifying of the cause of the malfunction, and in judging whether it was temporary or not.

### 2. LIST OF FREEZE FRAME DATA

LABEL (Intelligent Tester Display)	Measurement Item/Range	Diagnostic Note
INJECTOR	Injector	-
IGN ADVANCE	Ignition advance	-
CALC LOAD	Calculate load	Calculated load by ECM
VEHICLE LOAD	Vehicle load	-
MAF	Mass air flow volume	If value approximately 0.0 g/sec: <ul style="list-style-type: none"> <li>• Mass air flow meter power source circuit open or short</li> <li>• VG circuit open or short</li> </ul> If value 160.0 g/sec or more: <ul style="list-style-type: none"> <li>• E2G circuit open</li> </ul>
ENGINE SPD	Engine speed	-
VEHICLE SPD	Vehicle speed	Speed indicated on speedometer
COOLANT TEMP	Engine coolant temperature	If value -40°C, sensor circuit open If value 140°C, sensor circuit shorted
INTAKE AIR	Intake air temperature	If value -40°C, sensor circuit open If value 140°C, sensor circuit shorted
AIR-FUEL RATIO	Air-fuel ratio	-
PURGE DENSITY	Learning value of purge density	-
PURGE FLOW	Purge flow	-
EVAP PURGE VSV	EVAP purge VSV duty ratio	-
EVAP VAPOR PRES	EVAP vapor pressure	-
KNOCK CRRT VAL	Correction learning value of knocking	-
KNOCK FB VAL	Feedback value of knocking	-
ACCEL POS #1	Absolute No. 1 Accelerator Pedal Position (APP)	-

LABEL (Intelligent Tester Display)	Measurement Item/Range	Diagnostic Note
ACCEL POS #2	Absolute No. 2 APP	-
THROTTLE POS	Throttle position	Read value with ignition switch ON (Do not start engine)
THROTTLE POS	Throttle sensor position	Read value with ignition switch ON (Do not start engine)
THROTTLE POS #2	Throttle sensor position #2	-
THROTTLE MOT	Throttle motor	-
O2S B1 S2	Heated oxygen sensor output	Performing INJ VOL or A/F CONTROL function of ACTIVE TEST enables technician to check voltage output of sensor
AFS B1 S1	A/F sensor output	Performing INJ VOL or A/F CONTROL function of ACTIVE TEST enables technician to check voltage output of sensor
TOTAL FT #1	Total fuel trim	-
SHORT FT #1	Short-term fuel trim	Short-term fuel compensation used to maintain air-fuel ratio at stoichiometric air-fuel ratio
LONG FT #1	Long-term fuel trim	Overall fuel compensation carried out in long-term to compensate a continual deviation of short-term fuel trim from central value
FUEL SYS #1	Fuel system status (Bank1)	<ul style="list-style-type: none"> <li>• OL (Open Loop): Has not yet satisfied conditions to go closed loop</li> <li>• CL (Closed Loop): Using heated oxygen sensor as feedback for fuel control.</li> <li>• OL DRIVE: Open loop due to driving conditions (fuel enrichment)</li> <li>• OL FAULT: Open loop due to detected system fault</li> <li>• CL FAULT: Closed loop but heated oxygen sensor, which used for fuel control, malfunctioning</li> </ul>
O2FT B1 S2	Fuel trim at heated oxygen sensor	-
AF FT B1 S1	Fuel trim at A/F sensor	-
CAT TEMP B1 S1	Catalyst temperature	-
CAT TEMP B1 S2	Catalyst temperature	-
INI COOL TEMP	Initial engine coolant temperature	-
INI INTAKE TEMP	Initial intake air temperature	-
INJ VOL	Injection volume	-
AIR PMP PRS	Air pump pressure	(See page <a href="#">ES-354</a> )
AIR PMP PLS PRS	Air pump pulsation pressure	(See page <a href="#">ES-354</a> )
STARTER SIG	Starter signal	-
PS SW	Power steering signal	-
PS SIGNAL	Power steering signal (history)	This signal status usually ON until battery terminals disconnected
CTP SW	Closed throttle position switch	-
A/C SIG	A/C signal	-
ELECT LOAD SIG	Electrical load signal	-
STOP LIGHT SW	Stop light switch	-
BATTERY VOLTAGE	Battery voltage	-
ATM PRESSURE	Atmospheric pressure	-
SECOND AIR VSV	Secondary air injection system status	-
ACT VSV	A/C cut status for Active Test	-
EVAP VSV	EVAP purge VSV	VSV for EVAP controlled by ECM (ground side duty control)
FUEL PUMP / SPD	Fuel pump speed status	-

LABEL (Intelligent Tester Display)	Measurement Item/Range	Diagnostic Note
VVT CTRL B1	VVT control status	-
VACUUM PUMP	Key-off EVAP system pump status	(See page ES-390)
EVAP VENT VAL	Key-off EVAP system vent valve status	-
TC/TE1	TC and TE1 terminal of DLC3	-
AI STATUS	Secondary air injection system operation prohibit	(See page ES-354)
VVTL AIM ANGL #1	VVT aim angle	-
VVT CHNG ANGL #1	VVT change angle	-
VVT OCV DUTY B1	VVT OCV operation duty	-
FC IDL	Idle fuel cut	ON: when throttle valve fully closed and engine speed over 1,500 rpm
FC TAU	FC TAU	Fuel cut being performed under very light load to prevent engine combustion from becoming incomplete
IGNITION	Ignition	-
CYL #1	Cylinder #1 misfire rate	Displayed in only idling
CYL #2	Cylinder #2 misfire rate	Displayed in only idling
CYL #3	Cylinder #3 misfire rate	Displayed in only idling
CYL #4	Cylinder #4 misfire rate	Displayed in only idling
CYL ALL	All cylinder misfire rate	Displayed in only idling
MISFIRE RPM	Misfire RPM	-
MISFIRE LOAD	Misfire load	-
MISFIRE MARGIN	Misfire monitoring	-
ENG RUN TIME	Accumulated engine running time	-
TIME DTC CLEAR	Cumulative time after DTC cleared	-
DIST DTC CLEAR	Accumulated distance from DTC cleared	-
WU CYC DTC CLEAR	Warm-up cycle after DTC cleared	-
MODEL CODE	Identifying model code	TRN2###
FAN MOTOR	Electric fan motor	-
VAPOR PRESS	Vapor pressure	EVAP system pressure as read by canister pressure sensor
ENG OIL PRES SW	Engine oil pressure switch signal	Always ON while engine running
ENGINE TYPE	Identifying engine type	2TR
CYLINDER NUMBER	Identifying cylinder number	4 or 6
DESTINATION	Identifying destination	A (America)
MODEL YEAR	Identifying model year	200#
SYSTEM	Identifying engine system	GASOLINE (gasoline engine)